

# CHILL PILL™ MOBILE SPEAKERS



Congratulations on your new purchase! The Chill Pill™ mobile speakers will give you great sound and trouble-free operation with proper care.

Before you get started, please review this manual for important safety precautions, instructions, and other information.

Enjoy!

## User Guide

[www.chillpillaudio.com](http://www.chillpillaudio.com)

» compact » expandable » rechargeable » retractable » patented » balanced

## SAFETY PRECAUTIONS

- » Read and keep these directions.
- » Heed all warnings and follow instructions carefully.
- » Do not use in or near water.
- » Do not block the speaker vents. Ventilation should not be impeded by covering the ventilation openings.
- » Do not use near any heat sources such as radiators, heat registers, stoves, or any other apparatus that produces heat.
- » Do not push objects into apparatus vents or slots because fire or electric shock hazards could result.
- » Do not play music while charging unit.
- » For added protection during lightning storms, unplug the speakers from any device that is plugged into a wall outlet.
- » Operate the apparatus only from the low level audio line output jack of the computer or of an audio device.
- » Clean only with dry cloth.

## CAUTION

### TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK:

- » Do not expose unit to water or moisture.
- » Do not disassemble unit or remove any parts. Refer to qualified service professional for repair or replacement.



The lightning flash with arrow-head symbol within an equilateral triangle is intended to alert the user to uninsulated "dangerous voltage" within the unit's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to important operating and maintenance (servicing) instructions in the literature accompanying the unit.

### ATTENTION CALIFORNIA RESIDENTS:


This product contains a Lithium Ion battery—special handling may apply. Please recycle responsibly.

For details, visit:


[www.dtsc.ca.gov/hazardouswaste/perchlorate](http://www.dtsc.ca.gov/hazardouswaste/perchlorate).

## CONTENTS

- » 1. Chill Pill™ mobile speakers (includes attached USB and audio cables)
- » 2. USB to mini USB adapter




### » View of attached cables



## MODES

### » Travel Mode

The Chill Pill™ is comprised of two speakers that magnetically click together into a single unit. Keep the speakers clicked together while traveling.



### » Speaker Mode 1 (closed)

Separate the two components to utilize each speaker. Plug audio cable into iPod, iPhone, computer or other device with standard 3.5mm (1/8") audio jack.



### » Speaker Mode 2 (open)

For richer, more resonant sound from the Chill Pill™, twist counterclockwise to open the top of the speakers. Plug 1/8" audio cable into device as directed above.



» Tip: The tops of the Chill Pill™ mobile speakers have a spring loaded mechanism that will 'pop' open with a simple twist. See "Opening Speakers" for more information.

## opening speakers



### » Step 1

Hold the Chill Pill™ and notice the lock mark which indicates the resonance area of the speaker unit.



### » Step 2

Press the top of the Chill Pill™ speaker, using your thumb and forefinger.



### » Step 3

Rotate unit counterclockwise.




### » Step 4

Loosen top of speaker slowly, and it will 'pop' open.

## OPERATING SPEAKERS

The Chill Pill™ mobile speakers use a standard 3.5mm (1/8") audio cable, for use with any device that has an audio (line-in) or headphone jack.

- » 1. Open Speaker A (with attached USB cable), and connect to Speaker B (with mini USB port).
- » 2. Open Speaker B (with attached audio cable), and connect to the audio (line-in) or headphone jack of your device.




» Tip: To use your Chill Pill™ mobile speakers with the original (non-3G) iPhone, you must have an additional headphone adapter (sold separately).

## CHARGING SPEAKERS

When the LED light on the speaker turns red, the Chill Pill™ mobile speakers are low on power.

- » 1. Charge via USB Port: Plug USB cable into a USB 2.0 port on your computer.
- » 2. Charge via AC Power: The Chill Pill™ mobile speakers can utilize your iPod AC Adapter (sold separately). Simply plug the USB cable into the USB port of the adapter, and plug into a wall outlet.




When the Chill Pill™ mobile speakers are finished charging, the LED indicator will turn blue.

» Tip: Active charging session may take up to three (3) hours, depending on the charge amount in the battery. Charge lasts up to six (6) hours.


## DIAGRAM

An overview of the Chill Pill™ mobile speakers.

### » In Travel Mode:



### » In Speaker Mode 2 (open):



## COMPATIBILITY

The Chill Pill™ mobile speakers work with the following:

- » All iPods
- » iPod touch and iPhone (original iPhone requires headphone adapter, sold separately)
- » Any device with audio jack (speakers use standard 3.5mm (1/8") plug)

## SPECS

- Battery + Power
  - » Lithium DC5V
  - » USB 2.0 charge
- Dimensions (p/speaker)
  - » 1-3/4" h (closed)
  - » 2-1/2" h (open)
  - » 2" diameter
- Switches
  - » On/Off
  - » Volume Control
- 1 Year Limited Warranty

## CONTACT

Chill Pill™  
1673 Main Street, Waitsfield, VT 05673  
[www.chillpillaudio.com](http://www.chillpillaudio.com)